









Spostare su ON solo nell'ultimo videocitofono o citofono del montante.  
 Das letzte Video-Haustelefon der Steigleitung auf ON schalten.  
 Placer sur ON (MARCHE) du dernier vidéophone de la ligne montante.  
 Move to ON on the last video door entry unit of the riser.  
 Lieve ON al último videointerfono del montante.  
 Stel de laatste huistelefoon van de opgaande lijn in op ON.  
 Coloque em ON no último vídeo intercomunicador do montante.  
 Μετατοπίστε στο ON στο τελευταίο βιντεοθυροτηλέφωνο του ορθοστάτη



230V ~